

Gonzo's Stebil™ Wiring Harness

This wiring harness is designed to lay under the seat area and run up the frame and out the steering neck to power up an auxillary air horn.

It is best to remove the tank and seat to get it dressed in but not really necessary to remove the tank. All wire ends are marked on electrical tape that should be removed as it is installed.

Lay the harness under the seat and find a bolt to hook the frame ground wire to the frame of the bike.

 **Frame Ground**

Hook the fused battery wire to the positive side of the battery.

 **Battery Positive (+)**

Blue Wire Tap - Slip over stock horn wire and the trigger wire and clamp on with a pair of pliers. This will now trigger the relay and pass the full battery voltage to your new horn for optimal performance!

 Connect to new air horn connectors (+ and -).